



MOJO JL Full Shade Install

Inside the box

QTY (4) 11" bungee balls (Attached to the front the shade already)

QTY (14) 8" Bungee balls

QTY (2) 9" Bungee Balls (Attached to the rear corners of the shade already)

QTY (1) Plastic tool (16" long white plastic strip)

QTY (1) Clear vinyl bra for rear crossmember of roll bar

Step 1. Once your shade is taken out of the box and unfolded, lay it out in the sun for around 10 minutes. This will get the wrinkles out.

Step 2. Unroll the clear vinyl sticker and attach the three pieces to the rear crossmember of the roll bar. The sticker is cut in three pieces to make it easier to apply.



Step 3. Lay the shade over the top of the Jeep and begin the installation of the bungees.

Step 4. Start with the FRONT four 11" Bungees. Install the bungee through the front corner grommet hole inserting the bungee from the underside of the shade and pushing upward. Once you have the bungee in the hole, hook the plastic fishing tool to the bungee (non ball end)



Step 5. (Starting with the driver's side corner) Locate the corner windshield frame bolt. The two corner attachment points (Left and Right side) should be positioned to the outside of each of the front corner windshield bolts. With the two ends of the plastic fishing tool pinched, insert the tool in between the front roll bar and the windshield frame.



Step 6. Push the plastic tool through the gap between the roll bar and the windshield frame. You will see the pinched ends coming out of the gap next to the glass of the windshield. Pull the plastic tool all the way through the gap.



Attach the bungee end to the ball and repeat the same process on the passenger side corner attachment point. (Remember to put the bungee to the outside of the windshield mounting bolt)

Step 7. Repeat the same process for the two front center attachment points. The two center attachment points should be positioned to the outside of the center windshield bolts. Install the bungees.

Step 8. Attach the two 9" rear bungee balls to the REAR roll bar. Insert the bungee ball (From the top of the shade going down). Wrap the bungee around the rear roll bar post (These will be tight and you will have stretch the bungee ball.)



Repeat the process on the other rear corner. (You should now have the front four and the rear two bungee balls attached.)

Step 9. Attach the seven per side 8" bungee balls inserting the bungee from top down and wrapping around the roll bar to secure.



YOUR DONE!!

When putting the soft top back on the jeep, you will not have to remove any of the bungee balls and you can just leave the shade in place.

When installing the hard top back on the Jeep, you will need to remove the front bungees and the three side bungees. Once bungees are removed, fold front section of the shade back over the rear section (just past the rear of the freedom top rear latches) and finish installing the hard top and freedom panels.

